

EQXPTxx

EQXPT02 - Dual-Channel RTD Sensor Expansion Module for EQSP32



The <u>EQXPT02</u> is a **dual-channel RTD** sensor expansion module made for precise PT100 temperature sensor measurements in industrial applications. Designed to seamlessly integrate with the <u>EQSP32 Micro-PLC</u> Industrial IoT controller, it supports **PT100** sensors for 2-wire, 3-wire, and 4-wire configurations for maximum versatility.

With its compact, **DIN-rail mountable design**, the EQXPT02 integrates seamlessly into control cabinets, ensuring tidy and efficient wiring for automation systems. This streamlined approach makes it an excellent choice for professional installations in industrial environments

Designed for effortless integration, the EQXPT02 is automatically detected by the EQSP32 upon power-up, operating as a native peripheral. This plug-and-play functionality streamlines setup, enabling users to expand their system with minimal configuration.

The EQXPT02 features robust input **protection from over-voltage** conditions, making it ideal for demanding

The <u>EQXPT02</u> is a **dual-channel RTD sensor** expansion industrial environments. With its built-in shorted cable module made for precise PT100 temperature sensor and open cable detection, the module ensures reliable measurements in industrial applications. Designed to operation by quickly identifying potential wiring issues.

Equipped with a front-facing USB-C port, the module simplifies firmware updates to ensure access to the latest features and performance enhancements, without removing it from the setup. This straightforward update mechanism minimizes downtime and ensures the module remains optimized for your system's requirements.

Supported by the **EQ-AI** generative **AI** model, the EQXPT02 enables users to effortlessly generate the required code by describing their setup and desired functionality. This innovative approach accelerates the integration of the module into both new and existing EQSP32-based automation systems, making advanced industrial solutions accessible even to users with limited programming expertise.



KEY FEATURES

- Dual-channel support for PT100 RTD sensors
- 15-bit ADC resolution with a nominal temperature resolution of 0.032°C
- Supports 2-wire, 3-wire, and 4-wire configurations for maximum flexibility
- Compact DIN-Rail cabinet design for neat and organized installations
- Automatic module detection by EQSP32
- LED indicator for power and module status
- Front-facing USB-C connector for firmware update


- Built-in shorted and open cable detection for quick wiring issue identification
- Protected inputs against over-voltage conditions
- Generative AI Coding Assistant trained with EQSP32 Library and EQXPT features.
- Compact, 2SU-wide (36mm), DIN-rail mount enclosure with 12 screw terminals
- IP20 Protection
- -20 Min to 550 Max Ambient temperature

APPLICATIONS

- Industrial Control
- Environmental Monitoring
- Process Automation
- Food and Beverage Industry
- Energy Management Systems

- Pharmaceutical Production
- HVAC Systems
- Temperature-Sensitive Manufacturing
- Educational Projects

BLOCK DIAGRAM





SYSTEM SPECIFICATIONS

Section	Features		
Power Management	Supplied by the board-to-board connector		
RTD Inputs	2 x PT100 RTD Sensor Inputs		
	Supports 2-wire, 3-wire, and 4-wire configurations		
	15-bit ADC resolution, with a nominal temperature resolution of 0.032°C		
	Built-in shorted and open cable detection to identify wiring issues		
	Overvoltage protection		
la di sati sa s	Green LED for power indication		
Indications	Red LED for device status		
Enclosure	Easy standard DIN rail push-fit mounting with spring mechanism		
	IP20		
Expandability	Push fit expansion module mounting		
	Automatic module detection and characterization		
Firmware Update	Front-facing USB-C for easy firmware upgrades		
Environment	-20°C to 55°C		

ELECTRICAL SPECIFICATIONS

Absolute Maximum Values

Pin	Туре	Min.	Тур.	Max.	Unit
I+, I- to GND	Current Output	-50		50	V
M+, M- to GND	Analog Input	-50		50	V




CONNECTING EQXPT

To use the EQXPT RTD sensor expansion module, mount it next to the EQSP32 controller on the DIN rail and simply slide it until the board-to-board connector is fully inserted into EQSP32.


The expansion module is powered by the board-to-board connector and does not require an external power supply.

When adding additional modules, it is recommended that the power is disconnected from the system. After adding the expansion modules and powering up the system, EQSP32 will start the automatic detection and indexing process.

For safety and ease of use, it is strongly recommended that a main circuit breaker is used to completely isolate the AC/DC from the grid.



Slide EQXPT to connect on EQSP32



Connected EQXPT on EQSP32

Warning: Make sure that the appropriate ground fault circuit breaker, fuses or circuit breakers and any other necessary protective components are used if there is any risk of user electrocution.




VISUAL INDICATIONS

When the module is connected and the system is powered on, the POWER LED should light up solid green.

If the STATUS LED is solid red after the automatic detection, it means that the EQXPT module has encountered an internal issue.

During data exchange between the main EQSP32 unit and the EQXPT module, the STATUS LED will be flashing for each transaction.



Power LED

On - Powered On
Off - No Power
Status LED

Off - No errors, no communication

Flashing - Data exchange

On - Communication error






PINOUT

X1 – Screw terminal connector 1


USB-C – Firmware update port

X2 – Screw terminal connector 2



X1 – Screw terminal connector 1

X1 connector accommodates the connections for the RTD sensor 1. It includes terminals for the sensor's wiring and GND terminals for connecting the sensor shielding if available.



Name	Pin	Function	Туре
	GND	GND for sensor shielding (*)	SHIELDING
X1	l1+, l1-	Constant current source for generating voltage on the RTD	CURRENT OUT
	M1+, M1-	Analog voltage sensor for calculating the RTD resistance	ANALOG IN


Notes:

(*) The GND terminals are common with the system's GND

X2 - Screw terminal connector 2



X2 connector accommodates the corresponding terminal for wiring the RTD sensor 2.



Name	Pin	Function	Туре
	GND	GND for sensor shielding (*)	SHIELDING
X2	12+, 12-	Constant current source for generating voltage on the RTD	CURRENT OUT
	M2+, M2-	Analog voltage sensor for calculating the RTD resistance	ANALOG IN


Notes:

(*) The GND terminals are common with the system's GND

POWER DISTRIBUTION

EQXPT's internal systems are powered by EQSP32's power management unit via the board-to-board connector. The board-to-board connector carries the power lines for system operation and the communication bus for allowing the expansion modules to interact with the main EQSP32 unit.

EQXPT's control unit may also be powered by the front facing USB-C port. By connecting the RTD sensor expansion module via the USB port, the system's core will be powered on, allowing for easy firmware update without any external power supply.




Power distribution



RTD SENSOR INPUTS

Equivalent RTD Measurement Circuit



Equivalent RTD Measurement Circuit


4-Wire RTD

A 4-wire RTD offers highly accurate temperature measurement by eliminating lead wire resistance errors.

Two wires carry the excitation current to the RTD sensor (terminals I+ and I-), while the other two measure the voltage across the RTD element (terminals M+ and M-).

Since the voltage wires carry minimal current, their resistance has no impact on the measurement, ensuring precise detection of the RTD resistance.

If the RTD sensor is shielded, the shielding wire may be connected to the GND terminal.



4-Wire RTD wiring example




3-Wire RTD

A 3-wire RTD provides a balance between accuracy and simplicity by partially compensating for lead wire resistance.

Two wires carry the excitation current to the RTD sensor (terminals I+ and I-), while the third wire (terminal M-) measures the voltage across the RTD element, paired with one of the current-carrying wires (M+ terminal must be connected with I+).

This configuration reduces the effect of lead wire resistance, though it is not entirely eliminated.

For shielded RTD sensors, the shielding wire can be connected to the GND terminal.



3-Wire RTD wiring example

2-Wire RTD


A 2-wire RTD is the simplest configuration, suitable for applications where lead wire resistance has a minimal impact or accuracy is less critical.

Both excitation current and voltage measurement are carried by the same pair of wires (terminal I+ connected with M+ and terminal I- connected to M-), making the lead wire resistance a part of the total measured resistance.

This configuration is typically used for shorter lead lengths or less critical measurements.

If the RTD sensor is shielded, the shielding wire may be connected to the GND terminal.





2-Wire RTD wiring example

Library Reference				
Usage				
eqsp32.readPin(EQXPT(ii, nn))	Returns the temperature in degrees Celsius ii: number (index) of EQXPT module on the chain (*) nn: EQXPT channel number (1 or 2)			

Note:

(*) For 2 EQXPT modules connected on the main unit, the first one (closer to the main unit) will have an index of 1, the second EQXPT index of 2 etc.

The index refers only to the same type of modules. Different types of modules will be indexed with their own type.



BOOT BUTTON & FIRMWARE UPDATE

Boot Button

The Boot button is only used for entering EQXPT module into firmware update mode (or maintenance mode). To enter maintenance mode, keep the boot button pressed while powering up the module.

Another option is to keep the boot button pressed while sending a reset command to the module via the serial terminal.

Once the module is in maintenance mode, it will be shown as a storage device. Drag and drop the desired .uf2 firmware file into the RPI-RP2 storage device and the update will be performed automatically.

Once the update is done, the unit will be automatically rebooted.

Power cycle the system to trigger the automatic detection procedure and the system will be ready for normal operation.



MECHANICAL DIMENSIONS

All dimensions are measured in mm with a +/-0.1 tolerance.

